

500 WATT POWER CONVERTER

HD-170

110/120 Volt \rightleftarrows 220/240 Volt



Be certain that your selector (input) voltage is set to your power voltage. Using the incorrect selection may damage you equipment. A setting of 110 volts for a 220 volt item will result in an output voltage being reduced to half the rated voltage. A setting of 220 volts for a 110 volt item will result in the output voltages being 2 times greater than the rated voltage. A high humming sound will be heard. DISCONNECT IMMEDIATELY!

After the correct input voltage is selected, turn the unit on. Select the correct output voltage for your equipment, do not let it exceed the maximum capacity of the converter. Turn off the unit when it is not is use.

MANN LAKE
WE KNOW BEES

501 1st St S, Hackensack, MN 56452
500 Santa Anita Dr., Woodland, CA 95776
485 Stewart Rd, Wilkes-Barre, PA 18706
1600 Commerce Street, Marshall, TX 75672
301 Bert Schultz Blvd Winter Haven, FL 33881

Telephone: 800-880-7694
www.mannlakeltd.com